Sony Vaio PCG-F420 Battery Replacement

Written By: Mohan Singhal



INTRODUCTION

Removing the battery is the first step in any electronic device repair in order to ensure your safety and protect the device from any damage.

Step 1 — Battery



- The battery is located on the left side of the laptop as shown by the red circle.

Step 2



- Pull the plastic cover down (indicated by the arrow) and then swing it upwards to reveal the battery compartment.
- The battery can now be removed by pulling it.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 08:29:23 AM.